



ASSEMBLY INSTRUCTIONS FOR A 10 & 12 HOLE CONVENTIONAL NEST

10 HOLE

- A - 410900 - TOP (1)
- B - 410898 - RIGHT PARTITION (1)
- C - 410899 - LEFT PARTITION (5)
- D - 410725 - FRONT TOP PANEL (1)
- E - 410726 - FRONT BOTTOM PANEL (1)
- F - 410727 - BACK TOP PANEL (1)
- G - 410728 - BACK BOTTOM PANEL (1)
- H - 410735 - LONG PERCH ARM ASSY (2)
- I - 410734 - SHORT PERCH ARM ASSY (2)
- J - 410731 - WOOD DRILLED PERCH (3)
- K - 410730 - NEST BOTTOM (10)
- 410732 - HARDWARE BAG (1)
- L - 012802 - 3/16 POP RIVET (73)
- M - 012795 - #10-24 x 1/2 HEX HEAD SCREW (12)
- N - 012408 - #10-24 NUT (12)
- O - 010621 - 1/4-20 x 1-1/4 HEX BOLT (12)
- P - 012793 - 1/4-20 LOCKNUT (12)
- Q - 410719 - HANGING BRACKET (2)

12 HOLE

- A - 410748 - TOP (1)
- B - 410898 - RIGHT PARTITION (1)
- C - 410899 - LEFT PARTITION (6)
- D - 410714 - FRONT TOP PANEL (1)
- E - 410715 - FRONT BOTTOM PANEL (1)
- F - 410716 - BACK TOP PANEL (1)
- G - 410717 - BACK BOTTOM PANEL (1)
- H - 410735 - LONG PERCH ARM ASSY (2)
- I - 410734 - SHORT PERCH ARM ASSY (2)
- J - 410721 - WOOD DRILLED PERCH (3)
- K - 410720 - NEST BOTTOM (12)
- 410732 - HARDWARE BAG (1)
- L - 012802 - 3/16 POP RIVET (73)
- M - 012795 - #10-24 x 1/2 HEX HEAD SCREW (12)
- N - 012408 - #10-24 NUT (12)
- O - 010621 - 1/4-20 x 1-1/4 HEX BOLT (12)
- P - 012793 - 1/4-20 LOCKNUT (12)
- Q - 410719 - HANGING BRACKET (2)

INSTRUCTIONS:

Check all parts & read instructions prior to assembly. Lay top upside-down. Attach all partitions using 3/16 pop rivets. Turn nest over. Attach the (4) panels using 3/16 pop rivets, front top (notches & slots), front bottom (slots), back top (notches), & back bottom (no notches or slots). Attach long & short perch arms assemblies using 10-24 X 1/2 screws and nuts. Long assemblies goes through front bottom & short assemblies goes through front top. Attach (3) wood perches using 1/4-20 X 1-1/4 bolt & 1/4-20 locknuts. Bolt hanging bracket to the back of both corners using 10-24 X 1/2 screws & nuts.

